

This guide walks you through how to use your Rain Bird Wi-Fi enabled controller with the Amazon Alexa voice assistant. To enable Alexa with your Rain Bird controller you'll need to ensure you have:

- ▶ Rain Bird WiFi-ready controller with the LNK WiFi Module installed.
- ▶ An iOS or Android smart device with the latest Rain Bird App and Alexa App.
- ▶ An Amazon Echo smart speaker and an Amazon account.


! Note that only one Rain Bird controller can be linked to your Amazon account.

1 Activate Alexa in the Rain Bird app.


A. Download the latest Rain Bird app from either the Apple iOS or Google Play Store.




B. Open the Rain Bird app. (If you have not yet set up a Rain Bird WiFi controller on your Rain Bird App, visit wifi-pro.rainbird.com/support for instructions).




C. Select the **Controller** you want to link to Alexa.




D. Tap on the **Settings** icon.



E. Expand the **Connected Home** section in the **Settings** menu, and enter the controller password.




F. Enter the email address associated with your Alexa account.




G. Toggle the **Amazon Alexa** switch.



Note: If you later change the custom names of your programs or zones you'll need to return to this screen and tap **Sync Names with Alexa** to synchronize your new custom names.




H. Tap **Done**.




2 Add the Rain Bird Skill to Alexa.

A. Open the **Amazon Alexa** app.




(continued)


B. Select the **Menu** icon, then select **Skills** Search.



C. Search for the **Rainbird Skill** and select it.




D. Enable the **Rain Bird Skill**.




E. Enter the same Amazon account email you entered in the Rainbird app as well as your Rain Bird **controller** password.

Congratulations, your Rainbird Wi-Fi controller is now Alexa enabled.



3 Customize programs or zone names (optional).


A. Select the **Controller** you linked to Alexa.



B. Tap the **+/- ZONE** icon.



C. For example, you may enter **"Front Lawn"** as the name for zone 1, and tap **Done**. Remember to re-sync names with Alexa. (**Step 1G**).



4 Try it out with your Echo smart speaker.

Alexa recognizes hundreds of commands. Let's try a few.



Say: "Alexa, ask Rainbird to list my irrigation zones."

Alexa: "Ok, Zone 1 Front Lawn..."

Say: "Alexa, ask Rain Bird to water Front Lawn for 10 minutes!"

Alexa: "OK, I started Zone 1 Front Lawn for 10 minutes."

For a complete list of Rain Bird commands supported by Alexa, please visit wifi-pro.rainbird.com/Alexa